

WALL MOUNTING ISOLATING TRANSFORMER INSTALLATION AND SAFETY INSTRUCTIONS

Manufactured to BSEN 61558



1. Read all of these instructions before you use the transformer
2. These transformers are designed to provide mains isolation and reduce the mains voltage to a lower, safer value
3. Check the transformer case, plug and cable for signs of damage before use. Do not use if any damage is discovered
4. Check the transformer rating against the power usage of the equipment you are going to use
5. These transformers are rated for intermittent operation at their maximum listed power capability for a duty cycle of 25%. i.e. 5 minutes "ON" 15 minutes "OFF".
6. These transformers may be used in a continuous operation mode at a rating of 50% of their maximum capability. e.g. a 3.3kVA unit may be operated continuously at 1.65kVA
7. During normal operation these units will become warm. Ensure the transformer will not damage any floor covering it is standing on. It is not advisable to stand the unit on carpets, vinyl floor covering etc
8. This unit is fitted with a thermal trip device to protect against overload and short circuit
9. In the event of a short circuit to the output remove the cause of the fault before pressing the reset button on the thermal trip
10. In the event of an overload trip allow the unit to cool for at least 15 minutes before pressing the reset button
11. These units may be either hard wired to an electrical junction box or may be fitted with input leads and plugs. Units up to 3.3KVA may be fitted with a BS 1363 UK mains domestic style input plug and mains lead. Units rated above this level should be fitted with a suitably rated industrial style plug. The earth on the input plug must always be connected for complete safety to the output.
12. These units are designed for the equipment they are to power to be hard wired to the internal terminals on the output of the transformer. The earth lead must be connected for complete safety.
13. The 110V output of the transformer has a centre tap that has been connected to the incoming earth lead giving a 55V – 0 – 55V supply. The centre tap connection has been made with a removable link so the unit can be converted to a straight 0 – 110V supply. When converting ensure the label is marked to indicate the conversion
14. Connection leads should be secured through the walls of the enclosure with cable glands to prevent damage
15. Secure the wall panels and the lid of the enclosure after wiring before using the unit
16. These units are Class 1 insulated and must not be tested on Portable Appliance Testers (PAT) as Class 2 double insulated products. Flash test only at 1.5KV between input and earth **DO NOT** flash test output to earth
17. Transformers have an inherent high in-rush current at switch on. In the event of a supply fuse blowing check that the replacement is a suitably rated anti-surge type. Miniature Circuit Breakers (MCB's) protecting sockets should have a type C or D tripping characteristic
18. These units are protected against the ingress of solid and liquid contaminants to IP22 and are not designated for outdoor installation.
19. In the event of connecting an input lead and plug adopt the following wiring convention

Live	Brown Wire
Neutral	Blue Wire
Earth	Green / Yellow Wire

Ensure that such wiring is carried out by suitably qualified personnel